


# SABB DIESEL

MODEL H - HG

---

## ADDITIONAL INSTRUCTION AND PARTS LISTS



---

**SABB MOTOR A·S**

BOX 2626 – 5010 BERGEN, NORWAY

Telephone (05) 26 05 04–Telegram: "Sabbmotor"–Telex: 42559 sabb n

## **SUPPLEMENTARY INSTRUCTION AND PARTS LISTS FOR 8 HP SABB DIESEL MODEL H/HG**

**Models G 10 HP and H 8 HP are principally identical as to construction and parts. This manual contains the special for model H. The remaining instructions and parts lists are common for G and H.**

### **Model H/HG. SPECIFICATIONS:**

Continuous rating at 1500 r.p.m.:	6 HP
Continuous rating at 2000 r.p.m.:	8 HP
Cylinder bore/stroke . . . . .	90×90, 3.543/3.543
Piston top clearance incl. gasket:	0,5–1 mm/.019–.039 in.
Brake mean effective pressure, ab:	6,25 kg/cm <sup>2</sup> , 87,5 p.s.i.
Fuel consumption . . . . .	2 litres/h, 3,5 pints/h
Lubrication oil consumption . . .	2 g/hp-hour, .004 lb./hp-hour
Lubrication oil pressure, ab . . .	2,5–3,5 kg/cm <sup>2</sup> , 35–50 p.s.i.
Lubrication system . . . . .	Force feed by vane type pump
Full flow oil filter . . . . .	

### **Lubrication oil Capacities:**

Sump capacity . . . . .	2 litres, 3,5 pints
Clutch housing, model H . . . .	0,5 litres, .9 pint
Reverse gear, model HG . . . .	0,5 litres, .9 pint

**When ordering parts always give part number,  
part name and engine serial number.**

**ENGINE SERIAL NO.: .....**

## **OPERATION:**

Run engine carefully when new and increase load gradually during the first 25 operating hours. When setting the max. propeller pitch stop screw (see Instruction Book for Model G, page 4, pos. 25) choose the full speed r.p.m. between 1500 and 2000 where the boat gets good speed and the vibrations are light. See also page 21.

It is recommended to change lubrication oil after the running-in period. Also clean the magnet in oil sump and put it back.

After each starting and during operation check lub.oil pressure and cooling water temperature regularly. The lub.oil pressure gauge is fitted on lub.oil filter as standard. At normal speed the gauge shall register between 2,5 and 3,5 kg/cm<sup>2</sup> (35—50 p.s.i.).

When the engine is hot after long running the pressure may fall some. That is quite normal. At idling speed the pressure should not fall below 0,5 kg/cm<sup>2</sup> (7 p.s.i.).

The lub.oil pressure is determined by the pressure relief valve (in this book, pos. 16, page 7) which is fitted close to the vane pump. If unstable oil pressure, remove the relief valve and clean it. If oil pressure is low at start (when oil is viscous), clean sump filter.

## **LUBRICATION AND MAINTENANCE SCHEDULE**

### **EVERY 5 OPERATING HOURS (Daily).**

1. Check sump oil level with dipstick. Never let oil level sink below lowest mark.
2. Fill up oil cup on cylinder head cover with engine oil. Oil runs through wick tubes and drops on rocker arms and valve springs. If engine installation angle is steep the rear tube ends should be plugged or squeezed to permit oil reaching the front tube ends.
3. Give propeller greaser and stuffing box greaser one turn each.

### **EVERY 25 OPERATING HOURS (Weekly).**

1. Grease all nipples with grease gun. Use Multi Purpose grease.
2. Sliding bolts (see H sectional drawing, nipple no. 22) 5 shots.
3. Reversing bearing (nipple 19) 5 shots, and rear oil seals (nipple 20) 5 shots.


## **EVERY 50 OPERATING HOURS. Greasing of:**

1. Governor control handle and starting shaft.  
Clutch shaft and pitch control shaft bearings in reversing bracket.
2. Check lub.oil in clutch housing (H) or reverse gearbox (HG, dipstick).

## **EVERY 150 OPERATING HOURS: Lub.oil change.**

Engines with sump drain hand pump (delivered after H.72.1).

1. Unscrew "OIL" plug in crankcase cover.
2. Insert hand pump into sump and pump out. Use a tin or bottle under pump outlet.
3. Pour 1,5 litres new oil into sump through plug hole (2 litres including filter).



## **LUBRICATING OIL**

Use lubricating oil of good brand, "Service DG or DM".

### **VISCOSITY:**

Below 0° C temperature (+ 32° F) . . . . .	SAE 10
Between 0° C (32° F) and 30° C (86° F) . . . . .	SAE 20
Above 30° C (86° F) . . . . .	SAE 30
A multi-grade oil (SAE 10—20—30) can be used with advantage.	


## **EVERY 300. OPERATING HOURS (At least once yearly).**

1. Change lubricating oil filter in connection with oil change. Unscrew filter with the adjustable spanner. The filter can not be cleaned, but has to be replaced by a new. Type: Item PH9A. Apply film of engine oil to the gasket and hand turn filter until the gasket contacts its plate. Then tighten half a turn only. Pour 2 litres new oil into sump through plug hole. Start the engine and check for leaks. Check sump oil level with dipstick.

**EVERY 1200 OPERATING HOURS (or more often if required).**

1. Remove crankcase cover.
  2. Clean sump oil filter and crankcase interior.
  3. Remove and clean the sump magnet (Group H-20, pos 20).
  4. Wash interior with fuel oil and use rags to dry.  
Replace crankcase cover.
  5. Change lub.oil filter and fuel filter element.
  6. Pour 2 litres new oil into sump through plug hole.

**The Dynastarter V-belts should be tightened after the first 10-15 operating hours; later as required.**




## Group H-20. CYLINDER BLOCK

No.	Part Name	Part No.	No.	Part Name	Part No.
1	Cylinder block . . . . .	H23A	16	Liner flange ring . . . . .	823a
2	Cylinder liner . . . . .	H21N	17	Crankcase cover gasket . . . . .	822hb
3	Front bearing flange . .	H23LC	18	Bearing flange gasket ( $\frac{1}{64}$ "') . . . . .	823q
4	Crankcase cover . . . .	H22DC	19	Cyl. liner rubber ring ( $3 \times 94,5$ ) . . . . .	821p
5	Main bearing . . . . .	622h <del>621016</del>	20	Magnet . . . . .	923a
6	Cylinder head stud .. .	423a	21	Water temp. nozzle ..	652bg
7	Dipstick . . . . .	G23c-2	22	Washer, $\frac{3}{8}$ " . . . . .	723f
8	Filter bracket nut . . .	435L	23	Front oil seal (100-120-13) . . . . .	937bb
9	Fuel hose clip . . . . .	723jb	24	OIL-propp, $\frac{3}{4}$ " . . . . .	522dc
10	Thrust washer . . . . .	723cc	25	Fibre gasket . . . . .	882d
11	Grooved stud, $\frac{1}{8}$ " $\times$ 10 . . . . .	723f	26	Shield plate . . . . .	723e
12	Water inlet nipple, $\frac{1}{2}$ " . . . . .	511a			
14	Bolt ( $\frac{3}{8}$ " $\times$ $1\frac{1}{4}$ ") . . .	484c			
15	Cylinder head gasket	821r			


NOTE! Cylinder head for model H has a special swirl chamber insert H11jb, air intake tube H11k (175 mm) and valve push rods H34h (317 mm). The crankshaft end play is adjusted by means of the shims (Pos. 24, page 8). Correct end play 0,15—0,20 mm (.006—.008 in.) measured on cold motor.

SPARES: Cylinder head (with swirl chamber insert, valves with small parts, oil seal). Code: S1-G11A-H.



### Group H-23. LUBRICATING OIL PUMP


No.	Part Name	Part No.	No.	Part Name	Part No.
1	Lub.oil pump shaft ..	H23mc	11	Cotter pin, $5/32'' \times 1\frac{1}{4}''$ .. . . .	723m
2	Lub.oil pump vane ..	H23p	12	Dowel, $3/16'' \times 1''$ .. . .	442c
3	Spring .. . . . .	<u>723c</u>	14	Front bearing flange ..	H23LC
4	Needle bearing (Torrington B1112) ..	923b	15	Copper washer (NMR 49/7X) .. . . .	854g
5	O-Ring (Gaco SOR 16) .. . . .	823s	16	Lub.oil pressure valve ..	S1-H54g
6	Lub.oil pump housing ..	H23s	17	Sump strainer .. . . .	H67j
7	Lock washer, $\frac{1}{4}''$ JZ ..	745d	18	Sump filter nipple .. .	H67m
8	Bolt, $\frac{1}{4}''$ UNC×15 ..	445c	19	Pipe nut .. . . . .	553c
9	Bolt, $\frac{1}{4}''$ UNC×1 $\frac{1}{4}''$ ..	423s	20	Solder ring .. . . . .	565c
10	Nipple, $\frac{3}{8}''$ .. . . .	521b	21	Sump suction pipe ..	667j



## Group H-31. CRANKSHAFT

No.	Part Name	Part No.	No.	Part Name	Part No.
1	Crankshaft .. . . .	H31Ad	17	Crankshaft pinion key	434e
2	Connecting rod .. . .	2H32EC	18	Circlip (35i) .. . . .	732a
3	Big end bearing cap ..		19	Vibration damper drive gear .. . . . .	H32qb
*) 4	Big end half-bearing ..	2H32F <i>70.00 mm</i>	20	Vibration damper wheel .. . . . .	H23NB
5	Piston .. . . . .	2H32A	21	Bolt (1/4" X 15 B80) ..	445c
6	Gudgeon pin .. . . .	H32d	22	Lock washer, 1/4" JZ .	745d
7	Small end bush .. . .	632e	23	Bolt, M14 X 50 .. . . .	432g
8	Crankshaft pinion .. .	G31p	24	Shim, crankshaft, 0,2 mm .. . . . .	733k
9	Flywheel .. . . . .	H33AB		Shim, crankshaft, 0,08 mm .. . . . .	733kb
10	Top compression ring .. (Chromium pl.) .. . .	G32b	25	Stud, 1/4" X 28 .. . . .	433k
11	Compression ring .. .	G32bb	26	Flywheel ring .. . . .	H33k
12	Compr./scraper ring ..	G32bd	27	O-Ring, SOR 64 74,5 X 80,5 X 3	833k
13	Oil control ring .. . .	G32bc	28	Nut, 1/4" Nyloc .. . .	443b
14	Connecting rod bolt, M12 .. . . . . . . .	432.003			
15	Lock plate .. . . . .	733ab			
16	Flywheel lock pin ..	433f			


\*) undersize 69,75 2H32F6



### Group H-47. GEAR TYPE BILGE PUMP ASSEMBLY

No.	Part Name	Part No.	No.	Part Name	Part No.
27	V-belt, S-25	947u	39	Nut, $5/16"$	415e
34	Bolt, $3/8"$ UNC $\times 3/4"$	431b	40	Support screw, $5/16" \times 1"$ (against the crankcase)	421k
35	Flywheel pulley	G33DL	41	Gear type bilge pump complete (with bolt, pos. 14, green book)	S1-G47Q
36	Bilge pump bracket	H47p	41b	Gear type bilge pump complete with all pos.	S2-G47Q-H
37	Bolt, $3/8"$ UNC $\times 1\frac{1}{4}"$	484c			
38	Fibre gasket	847c			

(See group G-47 (Gear type bilge pump) in green Instruction Book and Parts List.





## Group H-68-1. DYNASTART

No.	Part Name	Part No.	No.	Part Name	Part No.
1	Dynastart, Bosch 12V 1 HK/14V 11A 0.010.350.004 . . . . .	968p	14	Bolt, $\frac{3}{8}$ " UNC×1"	421L
2	Kileremskive (SAV 75 A-2) . . . . .	H68p	15	Bolt, $\frac{5}{16}$ " UNC×1"	421K
3	Spring washer . . . . .		17	Bolt, $\frac{3}{8}$ " UNC× $\frac{3}{4}$ "	466b
4	Nut . . . . .		18	Washer, $\frac{3}{8}$ " . . . . .	781j
5	Dynastarter bracket ..	H68A	19	Spring washer, $\frac{3}{8}$ " ..	768a
6	Support bolt . . . . .	H68D	20	Elastic pin, $8\varnothing \times 24$ ..	734d
7	Support iron . . . . .	H68am	22	Nut, $\frac{3}{8}$ " . . . . .	415g
8	Bolt tightener . . . . .	H68aL	23	Nut, $\frac{5}{16}$ " . . . . .	415e
9	Bolt, $\frac{3}{8}$ " BSP . . . . .	468a	24	Lock washer, $\frac{5}{16}$ " ..	734h
11	Nut, $\frac{3}{8}$ " . . . . .	H68an	25	V-belt (A53) . . . . .	968pL
12	Spring washer, $\frac{3}{8}$ " ..	768a	26	Relay cable . . . . .	S1-968pp
13	Bolt, $\frac{3}{8}$ " UNC× $1\frac{1}{4}$ "	484c	27	Relay (ZAD 14V 11A Bosch 0.190.219.001) with relay cable . . . . .	S2-968pp

### LONGITUDINAL SECTION OF SABB DIESEL - MODEL H

- |                             |                                     |                            |
|-----------------------------|-------------------------------------|----------------------------|
| 1. Air intake               | 15. Pitch control lever             | 28. Clutch arm             |
| 2. Push rod                 | 16. Clutch crank                    | 29. Clutch clamp           |
| 3. Rocker arm adj. screw    | 17. Clutch housing cover            | 30. Starting pawl          |
| 4. Valve lub.cup            | 18. Clutch clamp nut                | 31. Pump housing oil seal  |
| 5. Decompression bolt       | 19. Reversing bearing grease nipple | 32. Water pump eccentric   |
| 6. Valve (inlet)            | 20. Rear oil seal grease nipple     | 33. Valve lifter (exhaust) |
| 7. Fuel leak-off pipe       | 21. Rear oil seal (double)          | 34. Lub.oil drain handle   |
| 8. Bosch injector           | 22. Sliding bolt grease nipple      | 35. Reduction gear         |
| 9. Lub.oil pressure gauge   | 23. Felt ring                       | 36. Sump oil filter        |
| 10. Lub.oil filter          | 24. Reversing ball bearing          | 37. Big end bearing        |
| 11. Precombustion chamber   | 25. Clutch sleeve                   | 38. Vibration damper       |
| 12. Torch paper holder      | 26. Clutch housing drain plug       | 39. Lub.oil vane pump      |
| 13. Wet type cylinder liner | 27. Sliding bolt                    | 40. Front oil seal         |
| 14. Piston                  |                                     |                            |





## Group H-68-2. DYNASTART

The dynastarter is a combined dynamo (12V—90W) and starter (1 hp) connected to engine flywheel by two V-belts.

**Fitting:** Attach Support Iron H68am to rear side of engine block. The Tap H68d is inserted in front and the Bracket H68A securely tightened. Then Dynastarter is mounted.

The Nut H68an has to be fitted correct way, locking against starter. Fasten Tightener H68al. Fit V-belts and tighten Bolt 421k lightly.



Use a heavy screw driver or spanner under the starter, bend up to tighten the belts and hold the lever until the bolts are securely fastened. Test tension by pressing belts midway between starter and flywheel. They should sag under thumb pressure about 1/8 inch. Tighten bolts again after some days of operation.

See that all wires are connected exactly as shown in diagram. The Regulator 968pk should be fitted conveniently near the engine, but rather not to the engine itself, protected against water and excess heat. All wires should be fitted neatly and away from the heat of the exhaust system and fastened with clips.



*Cont. page 17.*

## START


Open decompressor. Push starter switch in and turn clockwise. Close decompressor.



**WIRING DIAGRAM WITH V.D.O.  
EL. THERMOMETER AND TEMP. FEELER**




**WIRING DIAGRAM WITH SMITHS  
EL. THERMOMETER AND TEMP. FEELER**



### Group H-69-2 THERMOSTAT OPERATED SEAWATER COOLING.

No.	Part Name	Part No.	No.	Part Name	Part No.
1	Thermostat housing ..	G69D	9	Fibre gasket .. . . .	844b
2	Thermostat nipple ..	G69dk	11	Two way cock body .	G52k
3	Thermostat nut .. . .	G69dm	12	Two way cock .. . . .	G52m
4	Thermostat valve .. .	G69dL	13	Two way cock pin ..	553i
5	Thermostat (Behr-Thomsen X1.024.55.299) .. . .	969dL	14	O-ring (7,66×1,78) .	823c
6	Thermostat valve seat	G69dn	15	Spring .. . . . .	744b
7	Thermostat spring ..	769f	16	Nipple muff .. . . .	569d
8	Therm. release spring	769e	17	Pipe nipple (3/8" BSP)	521bb
			18	By-pass pipe .. . . .	669dn
			19	Two way cock pipe .	669dm



## Group H-600-1. WATER PIPES

No.	Part Name	Part No.	No.	Part Name	Part No.
1	Water pressure pipe ..	623ac	5	Pipe nut .. . . . .	511b
2	Water suction pipe ..	662b	6	Pipe nut .. . . . .	553c
3	Water discharge pipe ..	662e	7	Pipe collar .. . . . .	711c
4	Wet exhaust pipe ...	621c	8	Solder ring .. . . . .	565c

*Cont. from page 13.*

## GLOW/STARTER SWITCH – GLOW PLUG

The glow plug facilitates starting at low temperature (instead of starting cigarette). A special switch is used. Turn key clockwise to heat and keep for 10—20 sec. Then push in and turn clockwise again to start.

## BATTERY

Check regularly. The electrolyte level should not fall below the top of the plates and only distilled water used for topping-up. Clean battery top properly and keep the terminals and leads clean and tight. Coat the terminals with vaseline to prevent oxidization. Keep battery securely fastened.

**Electrical equipment is not covered by the engine's guarantee.**

